


SAFETY REQUIREMENT 15 Zone demarcation	 Balen/Pelt
Date of last modification:	7/9/2021
Nature of last modification: checked	

1	PURPOSE	2
2	SCOPE	2
3	DEFINITIONS	2
4	PRESCRIPTION	2
5	RIBBONS	2
6	FORECLOSURE	4

SAFETY REQUIREMENT 15

Zone demarcation



1 PURPOSE

Demarcate a zone to carry out work safely

2 SCOPE

The requirements of this safety regulation apply to the premises of Nyrstar Belgium.

3 DEFINITIONS

Tags: labels for hanging on sales ribbons

4 PRESCRIPTION

If it is not possible to eliminate the danger, then there must be a separation between man and danger. This can be done by placing a shield or deposition, for example a fence, poles with chains between them or with red-white or yellow-black tape. There are several temporary situations, in which the installation of a warning and drop-off signal is necessary because of the risks such as:

- maintenance: bumps, falling obstacles, hoisting.
- malfunction or calamity: do not enter space, environment.
- temporary construction and maintenance work: Excavations, demolition, obstacles, earthworks.

When one uses which shielding or deposition, one can best assess in the Task Risk Analysis.

5 RIBBONS

There are different types of tape, we use the red-white and yellow-black.

Red and white tape: Forbidden passage

Entering is NOT permitted

except for persons

involved in the works in the zone



This ribbon is used to demarcate a zone that one is not allowed to enter, unless one is involved in the works that are carried out there, similar to what prohibition signs impose on you.

SAFETY REQUIREMENT 15

Zone demarcation



Yellow-Black tape: Watch for danger

Entering allowed to everyone

AFTER evaluation of existing hazards



This ribbon is used to warn that dangers are present, such as warning signs indicating the dangers present.

Requirements for use

When applying tape, the following 2 points must be taken into account:

The deposit should be chosen in such a way that passers-by (e.g. pedestrians) are not unnecessarily hindered.

After the reason for applying the tape has been removed, it must be completely removed.

Identification of the tapes

To know who, when and why to place a ribbon, you need to use tags.

On it you can indicate the purpose or reason, who placed the ribbon, his telephone number and the date on which the ribbon was placed.



SAFETY REQUIREMENT 15

Zone demarcation



Drop off with traffic cones

In the event that work takes place that normally requires setting off the environment and this work takes place in a clear environment (e.g. open field), then marking by means of cones in a striking colour is sufficient.



6 FORECLOSURE

Shielding by means of fencing (rigid shielding) is mandatory for large construction sites, wells, excavations, demolition works and other situations where there is a risk of falling.